




DANGER

Danger of electrical shock, burns or death. Always remove all power sources before attempting any repair, service or diagnostic work. Power can be present from shore power, generator, inverter or battery. All power sources must be disabled and secured before performing any service.



CAUTION

If you lack the skills, tools or equipment to perform diagnostic or repair work leave such work to an authorized Winnebago Industries dealer or other qualified shop.



- ① USE WITH LOUNGE TABLE AND CHAIR
- ⑩ 22T VACUUM SYSTEM-CENTRAL.
- ⑨ SEE MANUFACTURER'S WIRING DIAGRAM FOR ADDITIONAL INFORMATION.
- ⑧ LOCATED ABOVE MICROWAVE.
- ⑦ WIRE ROUTED THRU FLOOR.
- ⑥ WIRE ROUTED BELOW MAIN FLOOR.
- ⑤ 54E WASHER/DRYER.
- ④ WIRE ROUTED IN ROOF.
- ③ WIRE ROUTED IN SIDEWALL.
- ② PROTECTED BY GFI OUTLET.
- ① LOCATED IN OVHD DINETTE CABINET.

98 Q37WP
265 CODE STANDARDS-CSA
78J ELECTRICAL SYS-50 AMP

TITLE: WIRING DIAGRAM-BODY 110V	
NO. OF SHEETS: 2	SHEET NO. 2 OF 2
DATE: 1.6	REV: 1.6
127116	