




DANGER

Danger of electrical shock, burns or death. Always remove all power sources before attempting any repair, service or diagnostic work. Power can be present from shore power, generator, inverter or battery. All power sources must be disabled and secured before performing any service.



CAUTION

If you lack the skills, tools or equipment to perform diagnostic or repair work leave such work to an authorized Winnebago Industries dealer or other qualified shop.



- NOTES:
- ⑤ LEAD SUPPLIED WITH CONVERTER.
 - ⑥ NOT USED WITH (68F) OR (73H) OR (78A)
 - ④ WIRE ROUTED THRU ROOF.
 - ③ WIRE ROUTED THRU SIDEWALL.
 - ② WIRE ROUTED THRU FLOOR.
 - ① ALL OUTLETS DOWN STREAM AND INCLUDING THIS OUTLET ARE GROUND FAULT INTERRUPT PROTECTED.

- (78A) TV-13" W/VCP-12V
- (73H) TV-19"/VCR/VIDEO SEL/SGL BNK
- (68F) TV-19"/VIDEO SELECT/SGL BNK
- (265) CODES/STANDARDS-CSA/CMVSS
- (12D) ELECTRICAL SYSTEM 30 AMP
- (1B1) CODES/STANDARDS USA

(1B1) (265) (12D)

WINNEBAGO 01 329N

| OF IN | DATE | UNSPECIFIED TOLERANCES ARE: | MATERIAL: |
|-------|------|-----------------------------|-----------|
| CHP | DATE | WHOLE OR 1/16" | |
| D/E | DATE | ONE-PLACE (1/32)" | |
| D/E | DATE | TWO-PLACE (1/64)" | |
| D/E | DATE | ANGLE | |
| CONP | DATE | THRU: WHOLE PROJECTION | |

DRAWN BY: _____ TITLE: **WIRING DIAGRAM-BODY 110V**
 CHECKED BY: _____ DATE: _____
 ALL DIMENSIONS ARE IN MILLIMETERS SHEET 1 OF 1 FILE NO. 134973