





- ③ USE WIRE LU WITH REAR CAP.
- ④ USE WITH FIBERGLASS TRANSITION PANEL.
- ⑤ USE WITH REAR AUTO HEATER.
- ⑥ USED ONLY IF TRAY IS NOT CHASSIS SUPPLIED.
- ⑦ SEE DRAWING 101128-01-000 WIRE ASM-CHASSIS NOTE 6 FOR LOCATION OF WIRE ASSEMBLY.
- ⑧ 4. USE WIRE TIES 8343-01-000 AND WIRE CLAMPS 10497-01-000 APPROXIMATELY 600 MM ON CENTER UNLESS OTHERWISE SPECIFIED.
- ⑨ 2. SECURE CONDUIT 41953-01-000 OVER ALL WIRES IN CONTACT WITH SHARP EDGES.
1. LEGEND: ——— FORD WIRING ——— WINNEBAGO WIRING ——— CABLE.



WINNEBAGO		91 W/IF427RT
DATE	UNSPECIFIED TOLERANCES ARE:	MATERIAL:
DRW	FINISH DIMS (18) ± 0.15	
SIZE	HOLE-PLATE (18.81) . . .	
FILE	HOLE-PLATE (18.80) . . .	
COLOR	ANGLE . . .	
LANDING NO.	THIS WIRE ASSEMBLY PRODUCTION	
TITLE: WIRING INSTL-CHASSIS		
DWG NO	SCALE: NONE	101059
ALL DIMENSIONS ARE IN MILLIMETERS		
SHEET 1 OF 1	REF: 100398	